Limitations

Eco-Friend

Flamauto is intended to extinguish fires of class A and class B, and is sutable for extinguishing of electrical devices. It is not capable to extinguish other classes of fire.

If Flamauto ampoule is broken or demaged, it will not activate automatically.

If Flamauto is not properly installed, its effectivness in fire extinguishing can be greatly reduced.

Even if we have evidence of Flamauto's funcionality up to 15 years after installation, we recommand to change it after 10 years, which is manufacturers guarantee.

Under ideal conditions Flamauto reaches its maximal effectivenes, but there are conditions which can limit its performance.

Warnings

If You use Flamauto as extinguishing hand grenade, dont throw it directly on burning oil or other liquid burning materials, as it can cause burning material to spread!

If liquid gets into eyes, rinse with water. It is not dangerous for normal skin.

If ampoule become broken for any reason, remove its liquid and broken glass with cleaning cloth.

Generally, one Flamauto unit is intended for effective extinguishing of a 12 m³ indoor fire, but if there are inflammable materials in environment, install Flamauto more densely.

If Flamauto unit is installed at the height of 2 meters, when activated, the liquid normally spreads 2,2 meters in width.

Flamauto is ecological, non toxic, environmental friendly product, so, after use or after end of its shelf life, it is not necessary to handle it as dengerous waste.

Manufactured by:

FLRMAR

Research, develop and manufacture of exceptional fire fighting systems

Marketed by:

FLRMAR

Flamark d.o.o. HR-10090 Zagreb Ante Topića Mimare 40 T: +385 (0) 1 77 91 7000 www.flamark.hr



Flamauto is an automatic fire extinguisher specially developed as a part of a fire protection system for transformer's hydrocarbon and oils.





www.flamark.hr

2015 05

Realiz

Installation and use

Installation and use

Automatic fire extinguisher, Flamauto is device intended for use as a part of a fire protection systems for professional electrical equipment.

It can be used for extinguishing of class A, B, C and class F fires, and is sutable for extinguishing of electrical devices.

Activation

Flamauto activates automatically if temeperature increases to over 84°C, and extinguishes fire in its initial phase. In such a way Flamauto saves expensive professional electrical equipment from major demages.

Flamauto's activation is practically impossible in any weather or climate, even if temeperature is below - 20° C and over +70°C.

Shelf life

When properly sealed, Flamauto liquid remains effective in over 15 years, without any maintanence. It requires only visual control.

Flamauto liquid and gas, which generates during the use, are harmless, and Flamauto is one really ecological product. It is not toxic, and dont requires special handling and recycling. Flamauto is intended to be installed in places with risk of fire, so that it works automatically, but it is also possible to use it as extinguishing hand grenade and throw it in the fire.

If it installes fixed, on the place of fire risk near electrical equipment, it is best to let trained staff to do it (chose a place, fix it and control it).

If You decide to install it self, do it this way:

- **1.** Remove glass ampoule from the holder.
- **2.** Attach the holder horizontally to the wall or ceiling, or another surface for mounting.
- **3.** Put the ampoule back in the holder, and control is it correctly fixed.

If You install it self, You have to follow next recommendations when choosing a place for installation and number of installed units:

- **1.** Above areas where fire can break out.
- **2.** Where temperature will be the highest in case of fire.
- **3.** Preferably 80 cm, but not higher than 2,5 meters from protected device.
- **4.** If there is oil or other inflammable materials around, install Flamauto densely.

If it uses like eqtinguishing hand grenade:

- **1.** Take it from the holder.
- **2.** Throw it against the wall or anything that would help the liquid to disperse over the burning area.

Dont throw it directly on burning oil or other liquid burning materials, as it can cause burning material to spread!







Disperison of liquid if Flamauto is installed on the wall.

Disperison of liquid if Flamauto is installed on the ceiling.





